

Rules 10-210, & 10-600 Meter Mounting Devices

Background:

Contractors have been required to use different models of meter-mounting devices for residential services based on availability due to supply chain issues. Neutral assemblies of meter-mounting devices can be installed at the factory, or be provided as a kit in 3 different versions:

- 1) Permanently bonded to the enclosure;
- 2) Permanently isolated from the enclosure; or
- 3) Supplied with means to bond or isolate from the enclosure, complete with marking on a temporary tag, instruction sheet, or equivalent indicating how the bond is to be removed or installed

It is important to check for the appropriate wiring configuration used based on the neutral assembly configuration. For example, an isolated neutral assembly requires a bond conductor to be installed in the service raceway (see Appendix B Figure B-10-4 and Bulletin 10-15-*) to the service box to prevent shock hazards and electrocution.

